

## Fitting a Scintex Snorkel to a Toyota Prado 120 Series

1. Out of the box (note: the stencil will be taped to the inside of the box);



2. Start with the end in mind



3. Remove the air filter to reveal the inner guard port





4. Tape the stencil to the outer guard aligning the straight edges



5. Drill pilot holes



6. Using hole saw, drill port for air pipe as per the stencil (3" saw used in photo).



7. Partially remove the the wheel inner lining to access between the inner and outer guard



8. Fit the interconnecting pipe, hose and clamps while re-fitting the air box.



9. Bolt up the snorkel so the upper mount can be located



10. Finish securing all bolts, fit the top snorkel air ram and reinstall the inner wheel arch lining. Enjoy your new snorkel!

